

Cast One Ultra

User Manual

配对中:蓝灯快闪

已连接:灯常亮

SBC:蓝色 ●

LDAC:绿色 ●

APT X:黄色 ●

APT X LL:白色 ○

APT X HD:紫色 ●

APT X HQ:青色 ●

APT X LOSSLEE:红色 ●

USB/PC/OTG
音频输入接口

音频流:常亮

Auracast模式:红灯



Cast One Ultra

蓝牙模式 :长按3S

蓝牙配对 :长按2S

切换协议 :双击

还原重 置 :长按8S

协议优先 : LDAC > aptX Lossless >
aptX HQ > aptX LL > aptX HD > aptX >
SBC

Auracast模式
还原重 置

:长按
:长按8S

Cast One Ultra

User Manual

Pairing:Flickering
Connected:The Light Stays On

SBC:Blue ●
LDAC:Green ●
APTX:Yellow ●
APTX LL:White ○
APTX HD:Purple ●
PTX HQ:Cyan ●
PTX LOSSLEE:Red ●

USB/PC/OTG
Audio Input Interface

Audio:The Light Stays On
Auracast Mode:Red



Cast One Ultra

Pairing:Short press
Bluetooth Mode :Long press 3S
Switch Code :Double Click
Reset :Long press 8S
Code Priority : LDAC > aptX Lossless >
aptX HQ > aptX LL > aptX HD > aptX >
SBC

Auracast Mode :Long press 3S
Reset :Long press 8S